

Setting Phone's Number:

00 NPA NXX XXXX *

EPROM AM27C020

Rate Description	Rate Band	Initial Charge	Additional Charge	Initial Time Limit	Additional Time Limit	Keypad Allowance	*
7-Digit Calls	6000	0025	0000	255	01	0008	*
Home Area Code Calls (10-digit or 1+10 digit)	6008	0025	0000	255	01	0008	*
411 & 1411 Information Calls	6082	0075	0000	255	01	0008	*
Incoming Calls	6088	0000	0000	255	01	0008	*
1+ 555-1212 Information Calls	6101	0075	0000	255	01	0008	*
1+ Area Code + 555-1212 Information Calls	6102	0075	0000	255	01	0008	*
1-800 Type Calls	6104	0000	0000	255	01	0008	*
408 area code (trial and error)	6067	0025	0000	255	01	0008	*
212 area code (trial and error)	6069	0025	0000	255	01	0008	*

- Note: some newer area codes don't seem to work, ie, 480 (Arizona)

To set something from options/registers manually:

1371* - Set register 137 to 1

13301* - set 1200 baud

1861* - set 1200 baud FSK

5067 480 * 520 * * (Add 480 and 520 area codes to rate band 67)

293 1111 * (Coin box amount security code)

Cable coming from the coin counter mechanism

Green: Ground

White: Quarter

Red: Dime

Blue: Nickel